



Universal Power Socket Panel

INSTALLATION GUIDE

Tools Required

Phillips Head Screw Driver
Cable Cutters
Cable Strippers
Cable Crimpers
Power Drill + Drill Bit

Additional Materials Required

1 x Spade Terminal Connector
1 x DC Positive Cable
1 x DC Negative Cable
1 x 20 Amp Inline Fuse

Installation

1. Isolate battery from system before installing the Universal Panel.
2. Connect both negative and positive cables to the Universal Panel connection points as specified below.
3. For safety purposes ensure you install an inline 20AMP fuse on the positive cable between the battery and the Universal Panel.
4. Connect cable ends to the negative and positive terminals of the battery.
5. Re-connect all other system cables to the battery.
6. Mount your panel to a flat, dry surface.
7. Turn the red isolation switch to the ON position and you're ready to go.

